



Engines 100.980 110 115 116 117 130  
Model year 1972–1974


### Engines 100.980, 116, 117


- Pull cylinder crankcase breather hoses from cylinder head covers.



### Engine 110


- Pull cylinder crankcase breather hose from air filter.






### Engine 130

- Pull cylinder crankcase breather hose from cylinder head cover.



### Engine 115

- Pull cylinder crankcase breather hose from cylinder head cover.



- Pull out flame guard filament with pliers.
- Clean filament in dry-cleaning gasoline and blow off.
- Install flame guard filament with long wire end in inward direction.